
LINK ALIGNMENT

It is crucial that the link is aligned on the main lobe and not on the secondary lobes. To do so, try several times until you get the best link performance.





ATTENTION:

Read this manual carefully before installation or maintenance procedures, which must be made by trained professionals. In all operations, you should use PPE's that have been duly approved for this purpose.

WARRANTY CONDITIONS

It is under installator's responsibility comply with the regulations applied to the installation, as well as following the instructions contained in this manual. Use only components and fasteners provided by ALGcom in the mounting kit.

Do at least one annual installation inspection to verify equipment conditions. Our products have a 3 years warranty from the date of invoice issuance.

To require the warranty, you must directly contact our CSR, by the contacts below: sac@algcom.com.br | +55 54 3201 1903

Point-to-point antennas' line, with excellent shielding.

NAME UHP-5800-32-09-DP

11510050144 V4

INSTALLATION GUIDE

FULL BAND PARABOLIC ANTENNA



GAIN FREQUENCY 4,9 - 6,425 GHz


ALGcom Quality and Safety WE HAVE A STRONG QUALITY POLICY





COMPONENTS


LETTER	DESCRIPTION	QUANTITY
А	REFLECTOR	1
В	MOUNTING HARDWARE	1
С	FEEDER	1
D	FIXING KIT	1
Е	V BOLT 3/8"	2
F	V BOLT 1/2"	1
G	ANTI-ROLL BAR	1
Н	PIPE CLAMP	1
1	M5 SCREW	3
J	1/2" SCREW KIT	1



TOOLS

DESCRIPTION

Wrench #19 Phillips Screwdriver #2 9/16" Wrench Allen Screw #5



Assembly of the model UHP-5800-32-09-DP. Image dimensions may be different in size.

